INSTRUCTION FOR USE
TRAVEL KETTLE
MODEL: TJ-50

Connection to main supply
Your kettle has a dual voltage selector on the underside of the kettle. Always check that you have selected the correct voltage before using the kettle. The kettle is of class 1 construction and should only be used in an EARTHED socket. Any travel plug adapter used MUST provide an earth connection.

Important Safety Instructions
- Read all instructions before operating this appliance for the first time. Failure to observe the instructions or misuse may result in personal injury.
- Avoid contact with steam coming out of the spout area when pouring and out of the lid when refilling.
- Keep children away from the kettle and never let the cord hang down over the worktop edge – a child could grab it and pull the kettle down.
- Never overfill – boiling water may splash out.
- If the kettle is overfilled, boiling water may be ejected.
- The appliance must not be immersed.
- The heating element surface is subject to residual heat after use.
- Never put the kettle, cord or plug in liquid.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This kettle is not intended for use by persons (including children) with reduced physical, sensory Or menteal capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for they safety..
- Children should be supervised to ensure they do not play with the appliance.
- This appliances is intended to be used in household and similar applications such as :
  - Staff kitchen areas in shops, offices and other working environment.
  - Farm houses.
  - By clients in hotels, motels and other residential type environments.
  - Bed and breakfast type environments.
  - To clean the surfaces in contact with water use a soft cloth and a mild detergent for cleaning.

Caution:
- Do not operate the kettle on an inclined surface.
- Make sure the lid is secure before switching the kettle on.
- Do not move while the kettle is switched on.

Warning: HOT SURFACE
- Avoid touching the surface of the unit with your bare hands when in use. Always handle the unit by the insulated carrying handle to protect yourself from injury.
- Do not open the lid while the water is boiling.
- Make sure the kettle is switched off before lifting or pouring.
- Unplug the kettle before filling or pouring.
- Never put the kettle near or on cooker hot plates or gas burners.
- This kettle is for boiling water only.
- This kettle is for domestic use only.
- Failure to observe these cautions may result in damage to the kettle.

Before using the kettle for the first time
- Remove all packaging and any labels.
- Fill to “MAX”, boil, then pour the water away.

To use your travel jug kettle
- Select the required voltage by turning the selector control. Always check that you have selected the correct voltage before using the kettle.
- Fill it through the spout or lid. The water level must not exceed “MAX” mark.
- Check the lid is closed.

- Plug in and switch on. The neon will come on.
- Your kettle will boil and switch off automatically. To re-boil the On/Off switch needs time to reset.
- Always unplug the kettle after use.
- If you find drops of water under your kettle, don’t worry – it is just condensation.

Boil-dry protection
If you switch on with too little water, your kettle will cut out automatically. Let it cool down before re-filling. When it has cooled down, the switch will reset itself.