


Specifications


- Battery Cell Type: Lithium-ion
- Capacity: 4400mAh
- Rated Input: DC 5V, 1500mA
- Rated Output: DC 5V, 2100mA(max)
- Charging Time: 4 to 6 hours
- Working Temperature: -10°C - +45°C
- Working Humidity: 65% - 25%
- Storage Temperature: -5°C - +35°C
- Storage Humidity: 65% - 20%
- Dimensions: 116x41x22mm
- Net Weight: 130g
- Devices Supported: iPhone, smart phones, mobile phones, MP3 players, MP4 players, PDAs, digital cameras, handheld game consoles, Bluetooth devices and so on.

How to Use


RECHARGE BEFORE FIRST USE




Charge Mobile Phones



Charge Digital Products




Charge the battery pack itself by an external AC power adapter



Charge the battery pack itself by a computer's USB port

Product View



- ① The power button
- ② Power indicator lights
- ③ Micro USB input port
- ④ LED small flashlight
- ⑤ USB output port

Charging Status

- When your device is being charged, the Power bank button lights will flash. When charging the Power bank, the button lights will illuminate sequentially. When charging is complete, the lights will illuminate constantly.
 - No.1 light means the power is less than 25%;
 - No.2 light means the power has reached 25-50%;
 - No.3 light means the power has reached 50-75%;
 - No.4 light means the power has reached 75-100%;
- Press the button for 3 seconds to turn on the LED torch.

Special Tips

- Choose the suitable connector according to your device and identify the Input and Output of the portable battery pack;
- Do not use the portable battery pack to charge the battery pack itself at the same time;
- If not in use, you are suggested to disconnect the external AC power adapter or DC cable with the portable battery pack;
- If the battery pack's output voltage is lower than the rated voltage /working voltage of your devices, it might not be charged or fully charged. But if the battery pack's output voltage is higher than the rated voltage/working voltage of your devices, and if the management system cannot support such situation, it might overcharge your devices or damage the battery pack itself or even damage your devices.

Safety Instructions

- Do not throw the portable battery into fires or try to heat it up. In such situations it might burn, explode or release toxic gas.
- Do not connect the positive and the negative poles directly;
Do not store it with other metallic materials.
Do not try to open it by yourself or break it.
Do not throw the battery pack into water or allow it to become wet. Please keep it dry.
- Do not use the portable battery pack if you notice it is leaking, heating itself, changing shape, smelling or any other abnormal phenomenon.
- Do not use if the temperature is above 60°C. The recommended usage temperature is between 15°C and 35°C.
- This product is not suitable for disabled people or individuals with limited intelligence or special needs (including children) unless there is a guardian present to supervise their safety and its correct usage.

Storage and Maintenance

If you do not use the portable battery for a long period, please follow the instructions below every 12 months to maintain its normal functions:

- First, fully charge the battery pack, then discharge the power by an outer device, finally, recharge it to half capacity, and store in a cool and dry place.
- It is recommended to do a complete charging and discharging every 3 months so as to ensure the best status of the battery cells inside.

Support

Please contact local distributor.

Made in China

KORJO™

4400mAh Portable Battery pack User Manual

Model PB 44

92mm

PB 44- 中性说明书

材质: 100G书纸

工艺: (CMYK) 四色印刷, 双面, 对折

尺寸: 50×92mm

50mm

50mm